


Montageanleitung Valtra N & T Serie



| NR | Stück | Part Nr | Benennung |
|----|-------|---------|----------------------------|
| A | 6 | A056 | Slider kpl. |
| B | 1 | A057 | Vesa Plate for AFS Pro 700 |
| BB | 6 | E187 | SCHEIBEN M8 |
| CC | 1 | E292 | Cup washer |
| D | 1 | E284 | Valtra Rail |
| DD | 1 | E293 | Cup washer |
| E | 1 | E285 | WG Valtra Bracket C-Pilar |
| EE | 1 | E294 | Schraube M12 |
| F | 1 | E286 | Valtra Bracket Middle |
| FF | 1 | E297 | Vierkant Rohrstopfen |
| G | 1 | E287 | Threaded washer |
| H | 3 | E288 | Spacer tube |
| H | 1 | E288 | Spacer tube |
| HH | 1 | E303 | WASHER |
| J | 1 | E289 | Kugelkopf |
| JJ | 4 | E304 | Sechskantschraube |
| K | 1 | E290 | Star knob M8 |
| KK | 1 | E307 | Adapter plate Index b |
| L | 1 | E291 | Lobe knobs |
| LL | 8 | E308 | Spring lock washer |
| MM | 4 | E221 | Mutter M6 |
| NN | 4 | E309 | Hex Bolt M6 |
| PP | 4 | A072 | Cable Clamp |
| R | 1 | E295 | WASHER |
| RR | 2 | E182 | KLEBEBAND doppelseitig |
| S | 1 | E296 | Stiftschrauben DIN 939 |
| U | 2 | E298 | Sechskantschraube |
| V | 1 | E299 | Sechskantschraube |
| W | 6 | E300 | Schraubenschutzkappe |
| Y | 1 | E301 | Schraubenschutzkappe |
| Z | 1 | E302 | O-Ring |